Manual Switches Indicators/Pushbutton Style

LED OR INCANDESCENT DISPLAY


* Notes:

install it in the housing.

(see pages 86 and 88).

MML41/46 Series

and strip/ matrix mount ** Rectangular housings only. *** No LEDs allowed.



FEATURES

• Accepts one LED or incandescent lamp

MML41 indicators resemble a pushbutton switch with the button in the "down" position.

78 Honeywell • Sensing and Control • 1-800-537-6945 USA • +1-815-235-6847 International • 1-800-737-3360 Canada

1. When an LED is specified in a rectangular MML46 listing, MICRO SWITCH will permanently

 MICRO SWITCH does not permanently install an LED in a square MML46 listing. To install an LED in a square housing, order a MML93L or MML93G receptacle and a MML92 LED

Manual Switches Indicators/Pushbutton Style

Example: MML41KA3K


Pushbutton style indicator housing (black); no bezel; support posts; black plunger.


Example: MML41KA3KRSDR

As above, except furnished with one red LED and red lens.

MML41/46 Series

Electrical Data	page 69
Lenses	page 80
Bezels	page 84
LEDs/Lamps	pages 85/87
Strip and matrix mountin	
Mounting dimensions	pages 92/94/95
PWB pin locations	pages 92/94





LED (Stanley type)					
Available in rectangular housings only.					
No LED					
D*:	Two LE	Ds:			
Red	RSRS	Red			
Yellow	YSYS	Yellow			
Green	GSGS	Green			
	e in rectang No LED D*: Red Yellow	e in rectangular housin No LED D*: Two LE Red RSRS Yellow YSYS	e in rectangular housings only. No LED D*: Two LEDs: Red RSRS Red Yellow YSYS Yellow		

Square housings accept only one LED. Only a two-character LED code is necessary. Example: MML46HR0**XX**DY.

Lens For LED display: For incandescent of DR Red non-lighted display:* DY Yellow DG Green LR Red LY Yellow LG Green LW White LK Black

	Legend				
or		With legend			
	Use Legend Order Sheet FO-74024 to cover each catalog listing.				

* When ordering incandescent or non-lighted display, LED field must be XXXX.